



CHICKEN COOP OPENER

AD006 • USER MANUAL

SET UP AND INSTALLATION

Step 1



Recommended Door opening size,
12" (30.48cm) high X 10" (25.4cm) wide.

Step 2



Use a level and make sure that the
door is level.
Screw the 4 (included) screws in the
left and right side rails.

Step 3



Remove 2 set screws in front of the
control panel.

Step 4



Gently, remove cover from the main
body to install 4 AA batteries.

Step 5




Install 2 screws at 10cm above the
controller to prevent the door from
tilting left and right.





CHICKEN COOP OPENER
08:12

Clock Setup

Press and hold the  arrow button for 2 seconds to initialize clock setup.


CURRENT TIME:
08:12

Current Time



Press the  arrow to scroll between hour, minutes. Press  arrow to adjust values.

Clock Setup



Timer operation

Timer operation allows users to set the time when the door will automatically opens or closes. Press  (the menu button) to enter set up menu.



OPERATING MODE:
TIMER-TIMER

Press the  arrow to change between TIMER-TIMER or LIGHT-LIGHT mode. Press  to adjust the mode.


OPEN UP TIME:
06:00

Press the  arrow to scroll between hour, minutes. Press  arrow to select open time.

CLOSE DOWN TIME:
09:18

Press the  arrow to scroll between hour, minutes. Press  arrow to adjust close time.


Light operation

Light operation allows users to set when the door will automatically opens or closes. The lumens are divided into 0-23, the lower the lumen value, the weaker the intensity of light. Press  (the menu button) to enter set up menu.


CURRENT LIGHT:
22

The value of current lumen, the higher the intensity of light, the stronger the lumen numerical values.


OPEN LIGHT SET..
03

Adjust the numerical value of light lumen value when the door should open. Press the  arrow to adjust numerical values (0-23).

CLOSE LIGHT SET..
09

Adjust the numerical value of light lumen value when the door should close. Press the  arrow to adjust numerical values (0-23).

PROTECT LEVEL:
05

Allow users to adjust protection levels (0-8 OFF). Press the  arrow to select levels.

SAVE AND EXIT
09:46

Press the  button to save the interface and settings.



- Hold ► arrow 4 seconds to temporarily close the door (The door will auto open after 3 minutes.)
- Hold ▲ arrow 4 seconds to temporarily open the door (The door will auto close after 3 minutes.)



Notes:

1. If an obstruction is encountered on the way up, the controller will show "Err". If this happens, remove obstruction, press the button to save the interface and setting again.
2. If you use the control mode "TIMER-TIMER", you can wait for the appropriate times to verify whether the auto function is correct.
3. The "LIGHT-LIGHT" control mode can be tested by covering the light sensor with an opaque material (such as a black cap). After waiting a few seconds, the door starts to lower. Once the door is at the bottom, remove the cap and the door will return to the top.

If you disconnect and reconnect the power, the controller will stay in sleep mode for 30 mins unless you press and go through the settings.